

XBIB-U-SS

Reference Guide

Programming Header
Header used to program
XBee Programmable
modules

Self Power Module

Advanced users only – will void warranty. R31 must be depopulated to power module using V+ and GND from J2 and J5. Sense lines can be connected to S+ and S- for sensing power supplies. **CAUTION:** Voltage not regulated. Applying incorrect voltage can cause fire and serious injury. See Note 1.

Current Testing

Depopulating R31 allows a current probe to be inserted across P6 terminals. The current though P6/R31 powers the module only. Other supporting circuitry is powered by a different trace.

Loopback Jumper

Populating P8 with a loopback jumper causes transmissions both from the module and from the USB to loopback.

DC barrel plug: 6-20V

Module can be powered by the USB or DC supply. When plugged in simultaneously the DC supply powers the board.

LED Indicator

Yellow: UART Tx, RF Rx
Green: UART Rx, RF Tx
Red: Associate

USB

RSSI Indicator

XBee Extraction Hole

Push up through hole to
remove XBee from socket

Test Points

Indicator LEDs

DS5: ON/ SLEEP
DS2: DIO12
DS3: DIO11
DS4: DIO4

SPI

SPI Power

Connect to power
board from 3.3V

Reset button

User Buttons

Connected to DIO lines
for user implementation

NOTE 1: Powering board with J2 and J5 without R31 removed can cause shorts if USB or barrel plug power is connected. Applying too high of a voltage will destroy electronic circuitry in the module and other board components and/or cause injury.

