




Typical Installation



Four Conductor Cable Options



Interface Connector




Solder to Flex Strip or use to connect Interconnect Cables and Controllers

5001- Bag of 100

5002- Bag of 6

Junction Blocks



5003- Right Angle Block

5004- four way angle Block

Four Conductor Interconnect Cables



5005- 20 cm 26AWG

5006- 100 cm 26AWG

5007- 250 cm 26AWG

5008- 20 cm 22AWG

5009- 100 cm 22AWG

5010- 250 cm 22AWG



Controller Cable

Solder to Flex Strip or use connect to Controller products

5011- 20 cm 22AWG